

spare part list: GH204 Elektra II



GH204337 ADHESIVE LABEL



GT104213
STRAIN RELIEF DEVICE




GT104415 DOVETAIL



GT104316 LEVER



GT104217
SPRING FOR LEVER 23



GT104218 INSULATING PLATE


spare part list: GH204 Elektra II



GT300224
OIL FELT 12x9



GT104225
FELT DISK F/TOP HOUSING



GT104227 SHACKLE



GT104244
SLIDE RING F/EXCENTER WHEEL



GT104249
SLIDE RING F/EXCENTER WHEEL



GT104614 CARBON BRUSH

spare part list: GH204 Elektra II



GT104319 BAERINGBUSH



GT104320 BAERINGBUSH



GT105326
PROTECTIVE SLEEVE



GT104801
MOTOR HOUSING-BOTTOM



GT104802
MOTOR HOUSING-TOP



GT104803 AIR FILTER


spare part list: GH204 Elektra II



GT104808
OSCILLATING ARM OF STEEL



GT104840 WORM WHEEL
W/EXCENTER & BEAR



GT104850 PRINTED CIRCUIT
BOARD, COMPLETE



GT104865 ROTOR PACKED



GT105819 SUITECASE and
TA013379 STICKER FOR
SUITECASE



GT604 OIL CANISTER PACKED

spare part list: GH204 Elektra II



TA004631 BALL BEARING DIN
625 5X 16X 5



TA003544 BALL BEARING DIN
625 7X 19X 6



TA003820 LOCKING WASHER
F/OSCILATNG ARM



TA013499 TORX-SCREW SN4850
M3x16 TX 8.8 VZ



TA013520 CABLE WITH PLUG



TA004691 SWITCH

spare part list: GH204 Elektra II



TA004627 SCREW DIN7971 M
2.2X 6.5 GALV



TA004663 CYLINDER SCREW
F/PLATES



TA004637 DISKS UNDERNEATH
WORM WHEEL



TA004639 SCREW F/SWALLOW
TAIL MOUNTING